Avolites Ltd. Engineering Change Notice

Title Diamond 4 motherboard reset cable

ECN Number ECN-0157

Equipment D4 Vision and D4 Elite

Author Adam Proffitt

Drawing Number
Date 31/03/05

Reason for ECN
Special Parts required
Special Tools required
None (An opened out small paper clip may be useful)

Work Required


Power off the desk.

You need to remove the reset wires from the motherboard power/reset/led connector.

The motherboard power/reset/led connector has connections for the power led, hard drive led, on/off switch and reset.


The two reset wires are in a sheathed cable (normally with a cable marker '3'). These two wires should be released from the connector block taking care not to disturb the other connections. The pins are released from the connector by pressing in the tab which can be seen on the edge of the connector - an opened out paper clip can be used for this.

The cable should then be pulled through the cable ties and removed from the desk.



For your information, the opposite end of the cable terminates near to the EZ-DMX board on the base of the desk, but will not be connected (see next photo).

Avolites Ltd. Engineering Change Notice



Now replace the motherboard power/reset/led connector.